

# FE100-25-EM


FlexPro® Series

**Product Status:** Active

## **SPECIFICATIONS**

Current Peak 50 A
Current Continuous 25 A

DC Supply Voltage 18 – 90 VDC Network Communication EtherCAT



The **FE100-25-EM** is a FlexPro<sup>®</sup> series servo drive with IMPACT™ architecture.

The **FE100-25-EM** offers full tuning control of all servo loops and is designed to drive brushed and brushless servo motors, and closed loop stepper motors. The drive accepts a variety of external command signals, or can use the built-in Motion Engine, an internal motion controller used with Sequencing and Indexing commands. Programmable digital and analog I/O are included to enhance interfacing with external controllers and devices.

The **FE100-25-EM** features an EtherCAT® interface for network communication using CANopen over EtherCAT (CoE) and USB connectivity for drive configuration and setup. All drive and motor parameters are stored in non-volatile memory.

IMPACT<sup>TM</sup> (Integrated Motion Platform And Control Technology combines exceptional processing capability and high-current components to create powerful, compact, feature-loaded servo solutions. IMPACT<sup>TM</sup> is used in all FlexPro® drives and is available in custom products as well.

#### **FEATURES**

- CoE Based on DSP-402 Device Profile for Drives and Motion Control
- Synchronization using Distributed Clocks
- Position Cycle Times down to 100μs
- Four Quadrant Regenerative Operation
- Programmable Gain Settings
- PIDF Velocity Loop

- Compact Size, High Power Density
- On-the-Fly Mode Switching
- On-the-Fly Gain Set Switching
- Dedicated Safe Torque Off (STO) Inputs
- Space Vector Modulation (SVM) Technology

	eedback upported	<ul> <li>Absolute Encoder</li> <li>BiSS C-Mode</li> <li>Incremental Encoder</li> <li>Hall Sensors</li> <li>Aux Incremental Encoder</li> <li>Tachometer (±10V)</li> </ul>	Motors Supported	<ul><li> Three Phase</li><li> Single Phase</li><li> Stepper</li></ul>	Modes of Operation	<ul> <li>Profile Modes</li> <li>Cyclic Synchronous Modes</li> <li>Current</li> <li>Velocity</li> <li>Position</li> </ul>
С	ommand Sources	<ul> <li>Over the Network</li> <li>±10V Analog</li> <li>Sequencing</li> <li>Indexing</li> <li>Jogging</li> <li>Step &amp; Direction</li> <li>Encoder Following</li> </ul>	Inputs / Outputs	<ul> <li>4 Programmable Digital Inputs</li> <li>3 Programmable Digital Outputs</li> <li>1 Programmable Analog Input</li> </ul>	Agency Approvals	RoHS UL/CE (Pending) TUV Rheinland (STO) (Pending)


# Sold & Serviced By:



www.electromate.com







# **INFORMATION ON APPROVALS AND COMPLIANCES**



The RoHS Directive restricts the use of certain substances including lead, mercury, cadmium, hexavalent chromium and halogenated flame retardants PBB and PBDE in electronic equipment.







**SPECIFICATIONS** 

3FECIFICATIONS			
5		al Specifications	
Description	Units	Value	
DC Supply Input Range	VDC	18 – 90	
DC Supply Undervoltage	VDC	15	
DC Supply Overvoltage	VDC	95	
Logic Supply Input Range (required) <sup>1</sup>	VDC	10 – 55	
Safe Torque Off Voltage (Default)	VDC	5	
Minimum Required External Bus Capacitance <sup>2</sup>	μF	50	
Maximum Peak Current Output <sup>3</sup>	A (Arms)	50 (35.3)	
Maximum Continuous Current Output <sup>4</sup>	A (Arms)	25 (25)	
Efficiency at Rated Power	%	99	
Maximum Continuous Output Power	W	2228	
Maximum Power Dissipation at Rated Power	W	23	
Minimum Load Inductance (line-to-line) <sup>5</sup>	μН	150 (@ 48VDC supply); 75 (@24VDC supply)	
Switching Frequency	kHz	20	
Maximum Output PWM Duty Cycle	%	83	
	Contro	l Specifications	
Description	Units	Value	
Communication Interfaces <sup>6</sup>	-	EtherCAT® (USB for configuration)	
Command Sources	-	±10 V Analog, Over the Network, Sequencing, Indexing, Jogging, Step & Direction, Encoder Following	
Feedback Supported	-	Absolute Encoder (BiSS C-Mode), Hall Sensors, Incremental Encoder, Auxiliary Incremental Encoder, Tachometer (±10V)	
Commutation Methods	-	Sinusoidal, Trapezoidal	
Modes of Operation	-	Profile Modes, Cyclic Synchronous Modes, Current, Velocity, Position	
Motors Supported <sup>7</sup>	-	Three Phase (Brushless Servo), Single Phase (Brushed Servo, Voice Coil, Inductive Load), Stepper (2- or 3-Phase Closed Loop)	
Hardware Protection	-	40+ Configurable Functions, Over Current, Over Temperature (Drive & Motor), Over Voltage, Short Circuit (Phase-Phase & Phase-Ground), Under Voltage	
Programmable Digital Inputs/Outputs	-	4/3	
Programmable Analog Inputs/Outputs	-	1/0	
Primary I/O Logic Level	-	5 VDC, not isolated	
Current Loop Sample Time	μS	50	
Velocity Loop Sample Time	μS	100	
Position Loop Sample Time	μS	100	
Maximum Encoder Frequency	MHz	20 (5 pre-quadrature)	
		cal Specifications	
Description	Units	Value	
Size (H x W x D)	mm (in)	38.1 x 25.4 x 16.0 (1.50 x 1.00 x 0.61)	
Weight	g (oz)	22.7 (0.8)	
Ambient Operating Temperature Range <sup>8</sup>	°C (°F)	0 – 65 (32 – 149)	
Storage Temperature Range	°C (°F)	-40 – 85 (-40 – 185)	
Relative Humidity	-	0-95%, non-condensing	
Form Factor	-	PCB Mounted	
P1 SIGNAL CONNECTOR*	-	80-pin 0.4mm spaced connector	
TERMINAL PINS	<u> </u>	26x Terminal Pins	
Notes			

### Notes

- 1. Applications with a logic supply voltage higher than 30VDC require a minimum external decoupling capacitance of 2.2µF / 60V film or 100µF / 100V aluminum added across LOGIC PWR and LOGIC GND.
- 2. External capacitance value assumes MLCC capacitors, 200V rating. For hybrid-polymer capacitor types, minimum external capacitance increases to 100µF / 100V. Capable of supplying drive rated peak current for 2 seconds with 2 second foldback to continuous value. Longer times are possible with lower current limits.
- 4. Continuous  $A_{\mbox{\scriptsize rms}}$  value attainable when RMS Charge-Based Limiting is used.

- Lower inductance is acceptable for bus voltages well below maximum. Use external inductance to meet requirements.

  EtherCAT® is a registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

  Maximum motor speed for stepper motors is 600 RPM. Consult the hardware installation manual for 2-phase stepper wiring configuration.
- Additional cooling and/or heatsink may be required to achieve rated performance.

#### \*Mating Connector Kit

Surface mount board connector for P1 and board spacers can be ordered as a kit using ADVANCED Motion Controls' part number KC-MC1XFE01.







#### PIN FUNCTIONS P1 – Signal Connector Description / Note Name GROUND Ground GND GROUND GND Ground PAI-1+ Differential Programmable Analog Input or DATA+ USB 1/0 USB Data Channel PAI-1-Reference Signal Input (12-bit Resolution) DATA- USB 1/0 THERMISTOR Motor Thermal Protection 8 GROUND Ground GND I<sup>2</sup>C Data Signals for Addressing, Network 9 GROUND Ground GND 10 SCLA 0 Error LED, and Bridge Status LED, See Differential Data Line for Absolute Encoders 11 ENC 1 DATA+ / A+ I/O 12 SDAA I/O Hardware Manual for more info. (BiSS: SLO+/-) or Differential Incremental 13 ENC 1 DATA- / A-1/0 14 HALL A ı Fncoder A Differential Clock Line for Absolute HALL B 15 ENC 1 CLK+ / B+ 1/0 16 Single-ended Commutation Sensor Inputs 1 Encoders (BiSS: MA+/-) or Differential 17 ENC 1 CLK- / B-1/0 18 HALL C Incremental Encoder B. GROUND GND GROUND GND 19 20 21 ENC 1 REF+ / I+ Differential Reference Mark for Absolute 1 22 ENC 2 A+ Ī Encoders (Leave open for BiSS) or Differential Incremental Encoder A. 23 ENC 1 REF- / I-Differential Incremental Encoder Index. 1 24 ENC 2 A-1 25 RESERVED Reserved. Do not connect. 26 ENC 2 B+ Differential Incremental Encoder B 27 RESERVED Reserved. Do not connect. 28 ENC 2 B-29 RESERVED Reserved. Do not connect. 30 ENC 2 I+ Differential Incremental Encoder Index 31 PDI-1 Programmable Digital Input 32 ENC 2 I-Programmable Digital Input Programmable Digital Output (TTL/8mA) 0 35 PDI-3 Programmable Digital Input 36 PDO-2 Programmable Digital Output (TTL/8mA) 0 37 PDI-4 Programmable Digital Input 38 PDO-3 Programmable Digital Output (TTL/8mA) 0 39 GROUND GND 40 GROUND GND 41 TX- IN 42 TX- OUT 0 Transmit Line OUT (100 Base TX) Transmit Line IN (100 Base TX) 43 TX+ IN 44 TX+ OUT 0 45 RX-IN 46 RX- OUT 0 Receive Line IN (100 Base TX) Receive Line OUT (100 Base TX) RX+ IN 47 48 RX+ OUT 0 49 +3V BIAS IN +3V Supply for Transformer/Magnetics Bias 0 +3V BIAS OUT +3V Supply for Transformer/Magnetics Bias 0 50 Link and Activity Indicator for IN port. Link and Activity Indicator for OUT port. 51 LINK/ACT IN Function based on protocol specification. 1/0 52 LINK/ACT OUT Function based on protocol specification. 1/0 See Hardware Information below. See Hardware Information below Run State Indicator for Network. Function RESERVED 53 STATUS based on protocol specification. See 1/0 54 Reserved. Do not connect. Hardware Information below. 55 RESERVED Reserved. Do not connect. 56 RESERVED Reserved. Do not connect. 57 RESERVED Reserved. Do not connect. 58 **RESERVED** Reserved. Do not connect. 59 GROUND Ground GND 60 GROUND Ground GND 61 RESERVED Reserved. Do not connect. **RESERVED** Reserved. Do not connect. 62 RESERVED Reserved. Do not connect. RESERVED Reserved. Do not connect. 63 64 RESERVED Reserved. Do not connect. RESERVED Reserved. Do not connect 65 66 67 RESERVED Reserved. Do not connect. 68 STEP Step Input. 1 69 RESERVED Reserved. Do not connect. 70 DIR Direction Input. 1 71 RESERVED Reserved. Do not connect. 72 RESERVED Reserved. Do not connect. +5VDC unprotected supply 73 +5V\_OUT 0 74 RESERVED Reserved. Do not connect. (See Note 1) +5V USER 76 +3V3 OUT +3.3VDC Supply Output for local logic 0 75 +5VDC User Supply for feedback and local 0 +5V\_USER 78 signals (100 mA max) logic (See Note 1) 0 +3V3 OUT 79 GROUND Ground GND 80 GROUND Ground GND 6 DATA- USB +3V3 OUT 76 -80-pin, 0.4mm spaced 4 DATA+ USB **Connector Information** +3V3 OUT 78 -: 88 connector GROUND 80 2 GROUND **Mating Connector Details** PANASONIC: P/N AXT380224 <u>ἀάλασοσοσορίζουσοσοσού</u> **Mating Connector** No Included with Drive GROUND 79 -- 1 GROUND +5V USER 77 -— 3 PAI-1+ +5V USER 75 – 5 PAI-1-

Notes

1. Total current through pins P1-73/75/77 should not exceed 300mA, while no single pin should be loaded more than 150mA.








# **TERMINAL PIN LOCATIONS**

The 26 Terminal Pins provide connection to the high power drive signals. Terminal Pins must be soldered to an interface board.



Pin	Name	Description / Notes	I/O			
T1	STO-1 INPUT	Safe Torque Off – Input 1	1			
T2	STO RETURN	Safe Torque Off Return	STORET			
T3	STO-2 INPUT	Safe Torque Off – Input 2	I			
T4	LOGIC PWR	Logic Supply Input (10 – 55VDC) (required). Applications using a logic supply voltage greater than 30VDC, with a mechanical switch and/or circuit breaker present on the logic supply rails, require an external decoupling capacitance of 2.2µF / 60V film or 100µF / 100V aluminum across LOGIC PWR and GND.	I			
T5	HV					
T6	HV	DC Supply Input (18-90VDC), Minimum $50\mu\text{F}$ / 200V external MLCC capacitance required between HV and POWER GND. For other capacitor types, minimum external capacitance increases to $100\mu\text{F}$ / $100\text{V}$ .				
T7	HV					
T8	T8 HV					
T9	HV	1				
T10	MOTOR C		0			
T11	MOTOR C	Nation Phono C. All provided all productions are designed as a state of providing and the state of				
T12	MOTOR C	Motor Phase C. All provided motor phase output pins must be used.				
T13	MOTOR C	1	0			
T14	POWER GND	Ground.				
T15	MOTOR B		0			
T16	MOTOR B					
T17	MOTOR B	Motor Phase B. All provided motor phase output pins must be used.	0			
T18	MOTOR B	7				
T19	POWER GND		GND			
T20	POWER GND	County				
T21	POWER GND	Ground.				
T22	POWER GND		GND			
T23	MOTOR A		0			
T24	MOTOR A	Motor Phase A. All provided mater phase output pies must be used	0			
T25	MOTOR A	Motor Phase A. All provided motor phase output pins must be used.				
T26	MOTOR A		0			

# **Terminal Pin Details**

Safe Torque Off (STO) Inputs

The Safe Torque Off (STO) inputs are dedicated +5VDC sinking single-ended inputs. For applications not using STO functionality, disabling of the STO feature is required for proper drive operation. STO may be disabled by following the STO Disable wiring instructions as given in the hardware installation manual. Consult the hardware installation manual for more information.








# HARDWARE INFORMATION

#### **LED Functionality**

LINK/ACT IN (P1-51); LINK/ACT OUT (P1-52); STATUS (P1-53);

The LINK/ACT IN, LINK/ACT OUT, and STATUS pins serve as EtherCAT network indicators. On a standard RJ-45 connector used with EtherCAT network topology, the typical EtherCAT network indicator LED locations are as shown in the below diagrams. Note that the drive features signals for connection to LEDs on an RJ-45 connector, but the connector itself is not included on the drive. The Development Card assembly FD060-25-EM features a built-in RJ-45 connector with LEDs for this purpose.



LINK/ACT IN and LINK/ACT OUT are used to drive the corresponding LINK IN and LINK OUT LEDs on a typical RJ-45 connector. The STATUS pin is used to drive the Status LED. The ERROR LED is driven by the I<sup>2</sup>C Data signals (P1-10/12). Consult the hardware installation manual for recommended wiring connections. The LED Function Protocol tables below describe typical LED functionality.

	LINK/ACT LEDS		
LED State	Description		
Green – On	Valid Link - No Activity		
Green – Flickering	Valid Link - Network Activity		
Off	Invalid Link		
	STATUS LED		
LED State	Description		
Green – On	The device is in the state OPERATIONAL		
Green – Blinking (2.5Hz – 200ms on and 200ms off)  The device is in the s		ate PRE-OPERATIONAL	
Green – Single Flash (200ms flash followed by 1000ms off)	The device is in state SAFE-OPERATIONAL		
Green – Flickering (10Hz – 50ms on and 50ms off)	The device is booting and has not yet entered the INIT state, or The device is in state BOOTSTRAP, or Firmware download operation in progress		
Off	The device is in state INIT		
	ERROR LED		
LED State	Description	Example	
Red – On	A PDI Watchdog timeout has occurred.	Application controller is not responding anymore.	
Red – Blinking (2.5Hz – 200ms on and 200ms off)	General Configuration Error.	State change commanded by master is impossible due to register or object settings.	
Red – Flickering (10Hz – 50ms on and 50ms off)	Booting Error was detected. INIT state reached, but parameter "Change" in the AL status register is set to 0x01:change/error	Checksum Error in Flash Memory.	
Red – Single Flash (200ms flash	The slave device application has changed the	Synchronization error: device enters SAFF-	

EtherCAT state autonomously: Parameter "Change"

in the AL status register is set to 0x01:change/error.

An application Watchdog timeout has occurred.

Sold & Serviced By:





Red - Single Flash (200ms flash

followed by 1000ms off)

Red – Double Flash (Two 200ms flashes separated by 200ms off, followed by


1000ms off)

Synchronization error; device enters SAFE-

**OPERATIONAL** automatically

Sync Manager Watchdog timeout.











#### PART NUMBERING AND CUSTOMIZATION INFORMATION E 100 - 25 - E M F **Drive Series Feedback** Multi Encoder (BiSS, 5V Incremental) FlexPro® **Environment Network Communication** EXtended Environment Ε **E**therCAT С **C**ANopen Form Factor RS485/232 FlexPro® Embedded **Continuous Current** FlexPro® E (W/ Development board) 5 **5**A FlexPro® Machine Mount 10 **10**A Maximum DC Bus Voltage **25**A 25 **50**A 50 060 60 VDC **60C 60**A (continuous only, no peak) 100 100 VDC

ADVANCED Motion Controls also has the capability to promptly develop and deliver specified products for OEMs with volume requests. Our Applications and Engineering Departments will work closely with your design team through all stages of development in order to provide the best servo drive solution for your system. Equipped with on-site manufacturing for quick-turn customs capabilities, ADVANCED Motion Controls utilizes our years of engineering and manufacturing expertise to decrease your costs and time-to-market while increasing system quality and reliability.

#### **Examples of Customized Products**

- Optimized Footprint
- ▲ Private Label Software
- ▲ OEM Specified Connectors
- No Outer Case
- ▲ Increased Current Resolution
- ▲ Increased Temperature Range
- Custom Control Interface
- ✓ Integrated System I/O

- ▲ Tailored Project File
- ▲ Silkscreen Branding
- ▲ Optimized Base Plate
- ▲ Increased Current Limits
- ▲ Increased Voltage Range
- ▲ Conformal Coating
- ▲ Multi-Axis Configurations
- Reduced Profile Size and Weight

Feel free to contact us for further information and details!

#### **Available Accessories**

ADVANCED Motion Controls offers a variety of accessories designed to facilitate drive integration into a servo system. Visit <a href="https://www.a-m-c.com">www.a-m-c.com</a> to see which accessories will assist with your application design and implementation.

#### **Development Board**

The FE100-25-EM is offered in a pre-soldered development board assembly to provide easy connections to motor, power, and signal functions. The development board assembly can be ordered as model number **FD100-25-EM**.



All specifications in this document are subject to change without written notice. Actual product may differ from pictures provided in this document.